## THANK YOU FOR CHOOSING A BAY CITY WOODWORKS MANTEL

## Suggested Installation for Mantel using the included Hanger Board system

The hanger board is only a suggested method; your installer may have an alternative method for mounting your mantel. Always consult a professional.

> WARNING! HEAT CLEARANCES MUST BE ADHERED TO FOR INSTALLATION OF THIS PRODUCT; ADHERE TO YOUR LOCAL BUILDING HEAT CLEARANCE CODES AND HEAT CLEARANCES AS STATED BY THE MANUFACTURER OF YOUR SPECIFIC FIREBOX OR STOVE MODEL. FAILURE TO DO SO WILL VOID THE PRODUCT WARRANTY. ALWAYS CONSULT A PROFESSIONAL.

Included in your carton: Mantel, Detached Mitered Hanger Board (Hardware to install detached hanger board NOT INCLUDED), Instruction Sheet.

Not included: Mounting hardware for detached hanger board. There are many different mounting surfaces, i.e. brick, stone, drywall...and each requires a different hardware for secure attachment. Always consult a professional.

Wood is combustible a material. Heat clearances must be adhered to. Before installing, adhere to your local building codes and manufacturer's requirements for your specific firebox or stove.

Do not proceed without full understanding of your firebox/fireplace wood clearance requirements and local building codes. Wood is combustible and required clearances must be adhered to or damage will occur to your mantel

## Measuring & Mounting

**NOODWORKS** 

Always check Building Codes and Heat Clearances; Wood is Combustible. Always attach hanger board to studs. Always consult a professional.

The Hanger Board system consists of 2 mitered hanger boards, one is attached to the back of the mantel and the other is packed separately in the carton and will attach to your mounting surface. When combined together, the mantel shelf will be locked in place on the wall.


\* Mounting hardware for detached hanger board is NOT INCLUDED.

We suggest that pilot holes be drilled into the hanger board prior to inserting the appropriate hardware for final installation on the wall. Always attach to studs.

If your mantel comes with a back panel that is tight to the attached wall hanger board, you must countersink the bolts and washers enough so the bolt heads are flush or below the face of the outside of the wall hanger board, as shown in (figure 3). If your shelf has an open back you will not need to countersink the bolts. (See figure-4)


Measuring: Measure from the bottom of the hanger board (A) to the bottom of the mantel (See Figure 1. below). This measurement is where the bottom of the mantel will be when mounted on the hanger board and this distance must be in compliance with heat clearances.

**DRAWINGS ARE FOR ILLUSTRATIVE PURPOSES ONLY** 



Centering: Find center point over firebox by measuring from one side to the other, mark the center point on mounting surface, do the same

for the hanger board. (See Figure 2. below) Figure 2.



NOTE: Gaps between the wall and the mantel may occur due to uneven walls or masonry. This is normal and is not a defect in your mantel.

WARNING! HEAT CLEARANCES MUST BE ADHERED TO ALWAYS CONSULT A PROFESSIONAL FOR INSTALLATION OF THIS PRODUCT; ADHERE TO YOUR LOCAL BUILDING HEAT CLEARANCE CODES AND HEAT CLEARANCES AS STATED BY THE MANUFACTURER OF YOUR SPECIFIC FIREBOX OR STOVE MODEL. FAILURE TO DO SO WILL VOID THE PRODUCT WARRANTY